








XS WIRELESS 2

Quick Guide


In the box	Vocal Sets		Instrument Set	Lavalier Set	Headmic Set
XS WIRELESS 2	XSW 2-835	XSW 2-865	XSW 2-CI1	XSW 2-ME2	XSW 2-ME3
 <p>NT 12-5CW</p>	●	●	●	●	●
 <p>SKM 835-XSW MZQ 1</p>	●	○	○	○	○
	○	●	○	○	○
 <p>SK-XSW</p>	○	○	●	●	●
 <p>ME 2-2</p>	○	○	○	●	○
 <p>ME 3-II</p>	○	○	○	○	●
 <p>CI 1-N</p>	○	○	●	○	○
 <p>2 x AA LR6 1.5 V</p>	●	●	●	●	●

Setup



SENNHEISER




Battery



Low battery



	~ 10 h
	~ 7 h
	~ 3 h
	Low Batt



Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com
Printed in Germany, Publ. 02/17, 571344/A03

Change frequency



Scan mode

Preset mode

Tune mode



SKM/SK Off!

606.500 MHz | ANT TUNE PRESET SCAN SYNC
 B. 1 CH. 01



SET

615.400 MHz | ANT TUNE PRESET SCAN SYNC
 B. 2 CH. 03

SET

606.500 MHz | ANT TUNE PRESET SCAN SYNC
 B. 1 CH. 01



SET

606.500 MHz | ANT TUNE PRESET SCAN SYNC
 B. 2 CH. 01




SET

615.400 MHz | ANT TUNE PRESET SCAN SYNC
 B. 2 CH. 03

Bank 0 only!





606.000 MHz | ANT TUNE PRESET SCAN SYNC
 B. 0 CH. 00




SET



606.025 MHz | ANT TUNE PRESET SCAN SYNC
 B. 0 CH. 00

Sensitivity


-  0 dB
-  -10 dB
-  -20 dB
-  -30 dB




OR



ME 2-2





ME 3-II



Squelch





min.
SQ 



max.
SQ 




Sync



Multichannel

Bank 1...8; U
CH. 01...12




Bank CH.	Bank CH.	Bank CH.	Bank CH.	
2 3	2 4	2 5	2 6	✓
1 1	1 2	1 3	1 8	✓
2 3	1 3	4 7	8 9	✗
2 3	2 3	2 3	2 3	✗

Min. distance



SKM





Guitar pickup






GA 1-XSW 2

Quick Guide



Mounting 1x EM-XSW 2






GA 2-XSW 2

Quick Guide

In the box



Mounting

